

Multifunctional Solar Folding Camping Light User Manual

Parts Diagram



Product Parameters

Material	ABS
LED Type	LED / XPG
Weight	206 g
Dimensions	(220 × 50 × 33) mm
Charging Time	Approx. 4 hours
Charging Current	500 mA
Runtime — High Mode	Approx. 3.5 hours
Runtime — Soft Mode	Approx. 7 hours

Folding and Rotating Operation

This product adopts a gear-type folding and rotating structure, with a maximum folding angle of 180° and a rotation angle of 270°. For specific operations, please refer to the following figure:



Switch Button Instructions

1. Single-press the main light: 5 modes in total (High → Low → Red Light → Red Light Flashing → Off).
2. Long-press for 1.5 seconds to switch to high beam: 4 modes in total (High → Low → Flashing → Off).
3. Long-press any mode for 1.5 seconds to switch between the main light and high beam at any time.
4. Any light source can be turned off with one key after being on for 10 seconds.

Charging Method and Precautions

USB Charging: Charge via the Type-C port.

Solar Panel Charging: This product is equipped with two solar panels, which can convert sunlight into electric energy to charge the battery.

- It is recommended to turn off the light before charging to ensure charging efficiency.
- The charging efficiency of the solar panels is affected by sunlight intensity, so please fully unfold the solar panels and face them toward direct sunlight.

Warnings

- Before using this product, please carefully read the manual for proper use and maintenance.
- Store in a cool and dry place, and avoid prolonged exposure to extreme environments above 60°C or below -40°C to prevent product damage.
- Children should use this product under adult supervision and guidance.
- Do not disassemble or modify this product yourself.