


M7-2

inverter.com



Multi functional Solar Work Light Flashlight

Product Name: Multi functional Solar Work Light Flashlight

◎ Color: Orange Black

◎ Material: Aluminum alloy+PC+ABSProduct size: Length 124 * Width 30 * Thickness 16

◎ Weight; 72 grams

Specification parameters

◎ Gear/Lumen: Main light high brightness (750 lumens), medium brightness (300 lumens), low brightness (120 lumens), side white brightness (120 lumens), side red light flashing, long press extremely bright mode (900 lumens)

◎ Battery life: Main light on for 1.5 hours, medium light on for 2.5-3 hours, low light on for 4.5 hours, side white light on for 2.5 hours, side red light flashing for 3.5 hours, front light extremely bright mode for 40 minutes

◎ Charging interface: Type-C charging interface

◎ Battery specifications: Built in 802060 lithium battery (1000mAh)

◎ Packaging method: Leather box packaging

◎ Lighting distance: 200-300 meters

◎ Item number; M7-2

Specific functions and features

1. The main light uses a high brightness wick with a maximum brightness of 750 lumens. Adopting dual lens focusing and long-range shooting for 150-200 meters
2. Up to 120 lumens of side white light can be used for close range floodlighting
3. Three side red flashing modes are used for warning or seeking help
4. Use TYPE-C on the side to charge the built-in battery with a voltage of 5V and a current of 0.5A
5. The back is equipped with a clip for easy use
6. The tail is equipped with a strong magnet for convenient use as a

work light

7.Press and hold the button in any state to activate the extremely bright headlight mode (900 lumens)

8.Double click the button in any state to activate the headlight flashing mode

9. This flashlight has a solar charging function. When illuminated, the green solar indicator light indicates that solar charging is in progress.

en fully charged, all 4-stage battery indicator lights will be on

Usage and precautions

1. .st gear and usage method: Main light high, medium, low, side white light mode, side red light flashing mode. Press and hold the button to start the extremely bright mode of the front lights in any state. Double click the button to start the flashing mode of the front lights in any state.

2. Battery level prompt: When the internal voltage of the flashlight is at normal value, the button indicator light is green. When the voltage is low, the red indicator light flashes to remind the user to charge in time

3. When using an external power source to charge the lamp, insert the factory configured charging cable into the charging interface opposite the switch. The red button indicator light will continue to flash during charging. When the battery indicator light turns green, it means that the battery is fully charged. Please unplug the charging head in a timely manner