

Manual

GK330 Solar Pump Inverter



Contact us...

Email: sales@inverter.com Phone: +1 800-585-1519 Website: www.inverter.com



INTRODUCTION

GK330 special inverters are developed for the power supply of water pumps based on the core control algorithm of GK3000 high performance inverters and the control requirements of PV water pumps.

All series products apply Infineon power modules. The function of Maximum power tracking, dormant at weak light, wake up at strong light, high water level dormant, underload pre-warning and other control protection functions can ensure normal operation of water pumps according to the customers' requirements to switch to the grid power supply.

•Through adopting advanced MPPT technology, this product can make full use of the efficiency of the solar cell array.

• It can automatically adjust the motor speed and the water flow along with the intensity of sunlight.

• Automatic sleep when on high-water level and automatic restart when on lowwater level to realize automatic control through water level.

• Can prevent pump from anhydrous idling;

• It also can enter automatically to sleep mode when the intensity of sunlight is weak (e.g. the sunset.), as well as can exit the sleep mode when the intensity of sunlight is becoming strong (e.g. the sun rise.).

• Protect itself in trouble and improve the reliability of whole system.

inverter....

| Chapter 1 Inspections and safety precautions1 |
|-----------------------------------------------------|
| 1-1. Product specifications1 |
| 1-2. Nameplate description2 |
| 1-3. Model description |
| 1-4. Technical Specification |
| 1-4-1. GK330 Technical Specification 3 |
| 1-5. Wiring Digrams5 |
| 1-5-1. Wiring Digrams below 11KW(3S1/3S2/2S3) 5 |
| 1-5-2.11KW~15KW wiring diagram(3N1) 6 |
| 1-5-3. Wiring diagram above 18.5KW(18.5-37kw) 7 |
| 1-6. Main circuit terminals8 |
| 1-6-1. GK330 Main circuit terminals 8 |
| 1-6-2. Description of cabling terminal functions. 9 |
| 1-7. Control circuit terminals9 |
| 1-7-1. Terminal arrangement of control circuit 9 |
| 1-7-2. Description of control circuit terminals 9 |
| Chapter 2 Function Code Table |
| Group P00: Monitoring Parameters |
| Group P01: Basic Parameters14 |
| Group P02: Motor 1 Parameters17 |
| Group P04: V/F Control Parameters |
| Group P05: Input Terminals19 |
| Group P06: Output Terminals22 |
| Group P07: Start/Stop Control24 |
| Group P08: Operation panel and display24 |
| Group P09: Auxiliary Functions25 |
| Group P10: Fault and Protection25 |
| Group P15: Special functions for PV inverters26 |
| Group P17: Function code management |
| Group P23: Control Optimization Parameters |
| Chapter 3 Commissioning guide |
| INDICATE: |
| 3-1.Wiring and commissioning steps |
| 3-1-1.Commissioning steps during power supply |
| 3-1-2.Commissioning steps during grid power supply |

inverter.....

| Chapter 4 | Faults and Solutions |
|-----------|-------------------------------------|
| 4-1. Fa | ult Information and Troubleshooting |
| 4-2. Co | mmon Faults and Solutions42 |
| Chapter 5 | Recommended solar panels |

I

I.

Chapter 1 Inspections and safety precautions

1-1. Product specifications

| | Functions | specifications |
|-------------|--------------------------|-------------------------------------------------------|
| | | AC380 3PH 380V(-15%)~440V(+10%) |
| | Input AC voltage (V) | AC220 Single phase 220V±15%, |
| | | AC220 3-phase 220V±15%, |
| | Maximum input DC bus | |
| 1 | voltage | 800000 |
| Input | Recommended DC bus | 540V/DC |
| | voltage | 540VDC |
| | Recommended MPPT | 450~750VDC (380VAC) |
| | range | 260~350VDC (220VAC) |
| | Input current(A) | Refer to the rated value |
| | Input current(Hz) | 50Hz or 60Hz, Allowed range:47-63Hz |
| | Output voltage(V) | 0-the input voltage |
| Output | Output current(A) | Refer to the rated value |
| Output | Output power(kw) | Refer to the rated value |
| | Output frequency(Hz) | 0~50Hz |
| | Control mode | SVPWM,SVC |
| | Motor type | Asynchronous motor |
| | Speed ratio | Asynchronous motor 1:100(SVC) |
| | Speed control accuracy | ±0.2%(SVC) |
| Control | Speed fluctuation | ±0.3%(SVC) |
| | Torque response | <20ms(SVC) |
| | Torque control accuracy | 10%(5VC) |
| | Starting torque | $0.25\Pi Z/150\%$ (SVC) |
| | Overload capability | 180% of rated current:10 seconds |
| | Overload capability | 200% of rated current: 1 second |
| | | Digital setting |
| | | Analog setting. |
| | Frequency | Pulse frequency setting, |
| | | Multi-step speed running setting, |
| | setting method | Simple PLC setting, |
| | | PID setting,MODBUS communication setting |
| | | Shift between the set combination and set channel |
| | Auto-adjustment of the | Keep a stable voltage automatically when the grid |
| Runnig | voltage | Voltage transients |
| control | Foult protection | Provide over 30 fault protection functions: |
| | Fault protection | Overbasting phase less and overlead etc. |
| | | Maximum power tracking pre-warning at weak light(A- |
| | | I S) auto wake up at strong light |
| | | Pre-warning when full water(A-tF).auto wake up at low |
| | Special functions for PV | water level, |
| | water pumps | Underload pre-warning(A-LL) and fault protection of |
| | | water level sensor (tSF), |
| | | When pre-warning, the inverter is in stand-by. |
| | Terminal analog input | <20m\/ |
| Deviational | resolution | -201114 |
| Peripheral | i erminai switch input | |
| interface | resolution | ≤20ms |
| | | |

| | Analog input | Analog input 1 channel (Al1) 0~10V/0~20mA, Analog input 1 channel (Al3) -10~10V |
|--------|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Analog output | Analog output 2 channels (AO1、AO2) 0~10V/0~20mA |
| | Digital input | 4 channels common inputs,the Max.frequency:1kHz, Internal impedance 3.3KΩ; 1 channel high speed input,the Max.frequency:50kHz |
| | Relay Output | 2 channels programmable relay output, RO1A ON, RO1B NC, RO1C common terminal RO2A ON, RO2B NC, RO2C common terminal Contactor capability:3A/AC250V |
| | keyboard | External (≤30m) |
| | Mountable mode | Wall mountable and flange mountable |
| Others | Temperature of the running environment | -10∼50℃,derate above 40℃ |
| Others | Average non-fault time | 2 years (25°C ambient temperature) |
| | Protective degree | IP20 |
| | cooling | Air-cooling |
| | Braking unit | embedded(≤15KW) |
| | EMC filter | Build-in C3 filter:meet the requires of IEC61800-3 C3 External filte:meet the requires of IEC61800-3 C2 |

1-2. Nameplate description





1-3. Model description



Pic 1-2 Model description

1-4. Technical Specification 1-4-1. GK330 Technical Specification

| Model | DC/AC Input voltage | Rated output Power(KW) | Rated input | Rated output | Adaptable motor |
|---------------|-------------------------------|---------------------------|----------------|-----------------|--------------------|
| GK330-0R4D-1B | | 0.4 | 5.4 | 2.1 | 0.4 |
| GK330-0R7D-1B | DC input: | 0.75 | 8.2 | 4.0 | 0.75 |
| GK330-1R5D-1B | 200-350vdc | 1.5 | 14.0 | 7.0 | 1.5 |
| GK330-2R2D-1B | AC input: 1-phase 220V±15% | 2.2 | 23.0 | 9.6 | 2.2 |
| GK330-004D-1B | | 3.7 | 34.0 | 17.0 | 3.7 |
| GK330-0R4D-2B | | 0.4 | 3.4 | 2.1 | 0.4 |
| GK330-0R7D-2B | | 0.75 | 5.0 | 3.8 | 0.75 |
| GK330-1R5D-2B | | 1.5 | 5.8 | 5.1 | 1.5 |
| GK330-2R2D-2B | DC input: | 2.2 | 10.5 | 9.0 | 2.2 |
| GK330-004D-2B | 260-350vdc | 3.7 | 14.6 | 13 | 3.7 |
| GK330-5R5D-2B | AC input: | 5.5 | 26.0 | 25 | 5.5 |
| GK330-7R5D-2B | 3-phase 220V±15% | 7.5 | 35.0 | 32 | 7.5 |
| GK330-011D-2B | | 11.0 | 46.5 | 45 | 11.0 |
| GK330-015D-2B | | 15.0 | 62.0 | 60 | 15.0 |
| GK330-018D-2B | | 18.5 | 76.0 | 75 | 18.5 |
| GK330-0R7D-3B | | 0.75 | 3.4 | 2.1 | 0.75 |
| GK330-1R5D-3B | | 1.5 | 5.0 | 3.8 | 1.5 |
| GK330-2R2D-3B | | 2.2 | 5.8 | 5.1 | 2.2 |
| GK330-003D-3B | | 3.0 | 7.9 | 7 | 3.0 |
| GK330-004D-3B | | 3.7 | 10.5 | 9.0 | 3.7 |
| GK330-5R5D-3B | DC input: | 5.5 | 14.6 | 13 | 5.5 |
| GK330-7R5D-3B | 450-750vdc | 7.5 | 20.5 | 17 | 7.5 |
| GK330-011D-3B | AC input: 3-phase 380V±15% | 11 | 26 | 25 | 11 |
| GK330-015D-3B | 1 | 15 | 35 | 32 | 15 |
| GK330-018D-3B | | 18.5 | 38.5 | 37 | 18.5 |
| GK330-022D-3B | | 22 | 46.5 | 45 | 22 |
| GK330-030D-3B | | 30 | 62 | 60 | 30 |
| GK330-037D-3B | | 37 | 76 | 75 | 37 |
| GK330-0R7D-4B | DC input: | 0.75 | 3.4 | 2.1 | 0.75 |
| GK330-1R5D-4B | 450-750vdc | 1.5 | 5.0 | 3.8 | 1.5 |
| GK330-2R2D-4B | AC input: | 2.2 | 5.8 | 5.1 | 2.2 |
| GK330-004D-4B | 3-phase 480V±15% | 3.7 | 10.5 | 9.0 | 3.7 |

I.

.

Chapter 1 Inspections and safety precautions



| Model | DC/AC Input voltage | Rated output Power(KW) | Rated input current(A) | Rated output current(A) | Adaptable motor |
|---------------|-------------------------------|---------------------------|------------------------------|-------------------------------|--------------------|
| GK330-5R5D-4B | | 5.5 | 14.6 | 13 | 5.5 |
| GK330-7R5D-4B | DC input: | 7.5 | 20.5 | 17.0 | 7.5 |
| GK330-011D-4B | 450-750vdc | 11.0 | 26.0 | 25.0 | 11.0 |
| GK330-015D-4B | AC input: 3-phase 480V±15% | 15.0 | 35.0 | 32.0 | 15.0 |
| GK330-018D-4B | | 18.5 | 38.5 | 37.0 | 18.5 |
| GK330-022D-4B | | 22.0 | 46.5 | 45.0 | 22.0 |
| GK330-030D-4B |] | 30.0 | 62.0 | 60.0 | 30.0 |
| GK330-037D-4B | | 37.0 | 76.0 | 75.0 | 37.0 |

Chapter 1 Inspections and safety precautions

1-5. Wiring Digrams

The inverter wiring includes main circuit and controlled circuit two parts. The user must be connecting wires right according to wiring diagram below.

1-5-1. Wiring Digrams below 11KW(3S1/3S2/2S3)



Pic 1-3 Wiring Diagrams below 11kw (3S1/3S2/2S3)

inverter....

1-5-2.11KW~15KW wiring diagram (3N1)



Pic 1-4.

11-15KW wiring diagram (3N1)

1-5-3. Wiring diagram above 18.5KW (18.5-37kw)



Pic1-5 Wiring diagram above 18.5KW(18.5-37kw)



1-6. Main circuit terminals 1-6-1. GK330 Main circuit terminals

1. Main circuit terminals below 15KW (380V)



2. 18.5KW~37KW(380V)Main circuit terminals



3. 30~37KW(380V)Main circuit terminals



| Terminal | Name | Description | | |
|---------------------|------------------------------------------------------------|--------------------------------------------------------|--|--|
| R/L1 | inverter never events | Connect to 3-phase AC power supply ,and | | |
| S/L2 | inverter power supply | single phase AC power connect to L1,L2 | | |
| T/L3 | input terminais | terminal | | |
| ⊕ /E | Grounding terminal | Connect to Ground. | | |
| U/T1 | in contan autout | | | |
| V/T2 | inverter output | Connect to a 3-phase motor | | |
| W/T3 | terminais | | | |
| ⊕ _{,РВ/} Θ | Connecting terminals of brake resistor or brake unit | Connect to the brake resistor or brake unit | | |
| _{₽,} ⊕ | Connecting terminals of DC reactor | Connect to an DC reactor (Remove the short jumper bar) | | |

1-6-2. Description of cabling terminal functions.

1-7. Control circuit terminals

1-7-1. Terminal arrangement of control circuit

1. 300SCB control circuit terminals



2. 300LCB control circuit terminals



TA1 TB1 TC1



inverter....

| Туре | Terminal | Name | Function Description | | |
|--------------------------------------|------------------------------------------------------------|----------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|
| | | | 1.Optical coupling isolation, compatible with | | |
| | | | dual polarity input . | | |
| | | | 2.Impedance : 2.4KΩ. | | |
| | | | 3.Voltage range for level input: 9-30V. | | |
| Input signal | DI6~DI8 | Digital input | Drain drive: PLC connects to 24V DC or | | |
| 0.9.1.1 | | terminal | external power. | | |
| | | | Source drive:PLC connect to COM. | | |
| | DI5 | High-speed pulse input terminal | Besides the features of DI1 \sim DI4 and DI6 \sim DI8, it can be used for high-speed pulse input. Maximum input frequency is :100KHz. | | |
| | | Positive port of | | | |
| Auxiliary power | +24V | the power | Maximum output :+24V/200mA,in no conditions can short connect COM with GND. | | |
| | СОМ | Common port | | | |
| Output signal | SPA/COM SPB/COM SP/COM TA1/TB1/TC1 TA2/TB2/TC2 | Digital output 1 High-speed pulse output terminal Output signal 3 | Optical coupling isolation, dual polarity open- collector output. Input voltage range:0-24V. Output current range:0-50mA. (24V DC/150mA) COM is the common terminal,output function. It is limited by P06.00 "SP terminal output mode selection", as high-speed pulse output, the maximum frequency hits 100KHz.As open-collector output, its specification is the same as that of SPA and SPB. Contact driving capacity : AC250V,3A,COSΦ=0.4 DC30V,1A | | |
| Analog Input/ Output signal | 10V→GND | Analog power | TA2 \rightarrow TC2 ON,TB2 \rightarrow TC2 NC. Provide 10V power supply to external unit,the maximum output current :10mA It provide power supply to external potentiometer with resistance range of 1KΩ- 5KΩ | | |

1-7-2. Description of control circuit terminals

inverter.....

Chapter 1 Inspections and safety precautions

| Туре | Terminal | Name | Function Description |
|--------------------------------------|----------|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Al1 | Multi-function analog input signal 1 | JP4 1-2 short circuit: 0- 10V input. JP4 2-3 short circuit: 4- 20mA input. Impedance :22kΩ(voltage input), 500Ω(current input) |
| | AI2 | Multi-function analog input signal 2 | JP3 1-2 short circuit: 0- 10V input. JP3 2-3 short circuit: 4- 20mA input. Impedance :22kΩ(voltage input), 500Ω(current input) |
| Analog Input/ Output signal | AI3 | Multi-function analog input signal 3 | JP52 1-2 short circuit: 0- 10V input. JP52 2-3 short circuit: 4- 20mA input. Impedance: 22kΩ(voltage input), 500Ω(current input) |
| | AO1,AO2 | Multi-function analog output signal | 1.JP2(AO1),JP41(AO2) 1-2 short circuit: 0- 10V. 2.JP2(AO1),JP41(AO2) 2-3 short circuit: 0- 20mA. |
| Auxiliary | CN5 | Extension card interface | 38-pin terminal, Optical external extension card(300EX_CARD,300IO1,300IO2,300PLC1 ,300PG1,300PG2,300RS485 extension card) interface. |
| Interface | J30 | Operation panel interface | Connect to internal /external operation panel interface. |

Chapter 2 Function Code Table

Function of GK330 series Inverters can be divided into 30 groups, namely P00~P30 according to the function; and every function group includes several function codes. The function code adopts three-level menu; for example, P08.08 means the eighth function code in P08 function group; and P16 is the manufacturer's function parameter and the user has no right to visit the parameter in this group.

inverter....

In order to make convenience for the setting of function code, group number of the function, number of function code and parameter of function code respectively corresponds with the first-level menu, the secondary menu and three-level menu when the operation panel is used for operation.

1. The content in the line of menu is as following:

The first line "NUMBER": it is the serial number for this function code in the whole function code; meanwhile, it also shows the register address for the communication.

The second line "CODE": it is the serial number for the parameter group of the function and parameter.

The third line "DESCRIBING LED/OLED KEYBOARD DISPLAY": it is the detailed description of this function parameter.

The fourth line: "SETTING RANGE" : it is the effective setting range of the function parameter and it is shown on LED / OLED operation panel.

The fifth line "FACTORY SETTING": it is the original set value for the function parameter when it leaves the factory; (P00 group have not this parameter)

The sixth line "ALTERATION": it is the alternative attributive of the function parameter (i.e. whether it allows alternation and alternating condition); and the inverter is as follow:

">" shows the set value of the parameter can be alternated whenever the Inverter is stopped or operated;

"
"
"shows the set value of the parameter can't be alternated when the Inverter operated;

"■" shows the value of the parameter is actual record value of the detection; and it can't be changed;

(the Inverter has made an automatic check and restriction on alternative attributive of every parameter and it can help the user to avoid wrong alternation.)

2. "Parameter system" is decimal system(DEC); if the parameter is shown via hexadecimal, every data is independent mutually when the parameter is edited; value range of partial bits can be hexadecimal $(0 \sim F)$.

 "Factory setting" shows the value after the parameter of the function code is updated when the operation of recovering factory parameter; parameter or record value of actual detection can't be updated.

4. In order to protect the parameter more effectively, the Inverter provides password protection for the function code. After the user password is set(namely, parameter for user password P07.00 is not 0), the system will firstly enter into the state of user password authentication when the user press regime to enter into the editing state of the function code; and then what is shown is"-----" the operator must input user password correctly, or the user can't enter. It is unnecessary to input manufacturer's password correctly for the parameter zone set the manufacturer. (warning: the user can NOT try to change the parameter set by the manufacturer; if the parameter is not set properly, it will easily cause the abnormal work or even destroy of the Inverter). The user

inverter....

password can be changed randomly under the condition that the password protection is unlocked; the user password is subject to the value input last. Set P07.00 to 0 can cancel the user password; if P07.00 is not 0 when electrify, then it shows the parameter is protected by password.

5. Function of user password also follows the above principle when the serial communication is used to change the parameter of the function code.

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify |
|------------------|----------------------------------------|------------------------|------------------|--------|
| P00.00 | Running Frequency(Hz) | 0-300.00Hz | • | 7000 |
| P00.01 | Set Frequency(Hz) | 0-300.00Hz | | 7001 |
| P00.02 | Bus Voltage (V) | 0-3000V | | 7002 |
| P00.03 | Output Voltage(V) | 0-1140V | | 7003 |
| P00.04 | Output Current(A) | 0-655.35A | | 7004 |
| P00.05 | Output Power(KW) | 0-32767KW | • | 7005 |
| P00.06 | Output Torque(%) | -200.0%-200.0% | • | 7006 |
| P00.07 | DI1-DI8 Input State | 0-32767 | | 7007 |
| P00.08 | SPA,SPB Output State | 0-1023 | • | 7008 |
| P00.09 | AI1 Voltage(V) | 0-10.57V 0-20.000mA | • | 7009 |
| P00.10 | AI2 Voltage(V) | 0-10.57V 0-20.000mA | • | 700A |
| P00.11 | AI3 Voltage(V) | 0-10.57V 0-20.000mA | • | 700B |
| P00.12 | Count Value | 0-65535 | • | 700C |
| P00.13 | Length Value | 0-65535 | | 700D |
| P00.14 | Load Speed | 0-65535 | | 700E |
| P00.15 | PID Setting | 0-100.0bar(kg) | • | 700F |
| P00.16 | PID Feedback | 0-100.0bar(kg) | • | 7010 |

Group P00: Monitoring Parameters



Chapter 2 Function Code Table Group P01: Basic Parameters

| Function Code | LED/OLED Operation | Setting range | Factory settings | Modify | Address |
|------------------|-------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| P01.00 | G/P type display | 1:G type(constant torque load) 2:P type (variable torque load e.g.fun and pump) | 1 | • | F000 |
| P01.01 | Motor 1 control mode | 0:Sensorless Vector Control (SVC) 1:Closed-Loop Vector Control (FVC) 2:Voltage/Frequency Control (VF) | 2 | | F001 |
| P01.02 | Command source selection | 0:operation panel control(LED OFF) 1:terminal control(LED ON) 2:communication control(LED blinking) 3:when power-on, Run automatically(LED OFF) | 0 | \$ | F002 |
| P01.03 | Main frequency source X selection | 0:Digital setting (Preset Frequency is P01.08 UP/DOWN can be modified,non- retentive at power failure) 1:Digital setting (Preset Frequency is P01.08, UP/DOWN can be modified,retentive at power failure) 2:Digital setting (Preset Frequency is P01.08,non- retentive at power failure) 3:Digital setting (Preset Frequency is P01.08, retentive at power failure) 4:Al1 5:Al2 6:Al3 7:Pulse setting(DI5) 8:Multi-reference 9:Simple PLC 10:PID 11:communication setting | 0 | | F003 |
| P01.04 | Auxiliary frequency source Y selection | The same as P01.03 (Main frequency source X selection) | 0 | | F004 |
| P01.05 | Range selection of auxiliary frequency Y for X and Y operation | 0:Relative to maximum frequency 1:Relative to main frequency X | 0 | \$ | F005 |
| P01.06 | Range of | 0%~100% | 100% | \diamond | F006 |



| | | Ch | apter 2 | Func | tion Code Ta |
|----------|------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|------------|--------------|
| Function | LED/OLED | | Factory | | |
| Code | Operation panel display | Setting range | settings | Modify | Address |
| | auxiliary frequency Y for X and Y operation | | | | |
| P01.07 | Frequency source selection | Unit's digit:Frequency source selection 0:Main frequency source X 1:X and Y operation (operation relationship determined by ten's digit) 2:Switchover between X and Y 3:Switchover between X and"X and Y operation" 4:Switchover between Y and"X and Y operation" Ten's digit:X and Y operation relationship 0:X+Y 1:X-Y 2:Maximum 3:Minimum | 00 | \$ | F007 |
| P01.08 | Preset frequency | 0.00Hz~Maximum frequency(P01.10) | 50.00Hz | \diamond | F008 |
| P01.09 | Rotation direction | 0:Same direction 1:Reverse direction | 0 | \diamond | F009 |
| P01.10 | Maximum frequency | 50.00Hz~300.00Hz | 50.00Hz | | F00A |
| P01.11 | Source of frequency upper limit | 0:Set by P01.12 1:Al1 2:Al2 3:Al3 4:Pulse setting 5:Communication setting | 0 | | F00B |
| P01.12 | Frequency upper limit | Frequency lower limitP01.14~Maximum frequency P01.10 | 50.00Hz | \diamond | F00C |
| P01.13 | Frequency upper limit offset | 0.00Hz~Maximum frequency P01.10 | 0.00Hz | \diamond | F00D |
| P01.14 | Frequency lower limit | 0.00Hz~Frequency upper limit P01.12 | 0.00Hz | \diamond | F00E |
| P01.15 | Carrier frequency | 0.5kHz∼16.0kHz | Model dependen t | \diamond | F00F |
| P01.16 | Carrier frequency adjustment with | 0:No 1:Yes | 1 | \diamond | F010 |

-



| Function | LED/OLED | | Factory | | |
|----------|----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|------------|---------|
| Code | Operation panel display | Setting range | settings | Modify | Address |
| | temperature | | | | |
| P01.17 | Acceleration time 1 | 0.0s∼6500.0s | Model dependen t | \diamond | F011 |
| P01.18 | Deceleration time 1 | 0.0s~6500.0s | Model dependen t | \diamond | F012 |
| P01.19 | Acceleration/D eceleration time unit | 0:1s 1:0.1s 2:0.01s | 1 | | F013 |
| P01.20 | Power-on Auto run time delay setting | 0.0s~3600.0s | 10.0s | \diamond | F014 |
| P01.21 | Frequency offset for auxiliary frequency source X and Y operation | 0.00Hz∼maximum frequency P01.10 | 0.00Hz | \diamond | F015 |
| P01.22 | Frequency reference resolution | 1:0.1Hz 2:0.01Hz | 2 | | F016 |
| P01.23 | Stop memory selection of digital set frequency | 0:No memory 1:Memory | 1 | \diamond | F017 |
| P01.24 | Motor selection | 0:Motor `1 1:Motor `2 2:Motor `3 3:Motor `4 | 0 | | F018 |
| P01.25 | Acceleration/D eceleration time base frequency | 0:Maximum frequency(P01.10) 1:Set frequency 2:100Hz | 0 | | F019 |
| P01.26 | Base frequency for UP/DOWN modification during running | 0:Running frequency 1:Set frequency | 0 | | F01A |
| P01.27 | Binding command source to frequency source | Unit's digit :Binding operation panel command to frequency source 0:No binding 1:Frequency source by digital setting 2:Al1 3:Al2 4:Al3 5:Pulse setting(DI5) | 0000 | \$ | F01B |



Function Code Table

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|--------|---------|
| | | 6:Multi-reference 7:Simple PLC 8:PID 9:Communication setting Ten's digit: Binding terminal command to frequency source Hundred's digit: Binding communication command to frequency source Thousand's digit: Binding auto-running to frequency source | | | |
| P01.28 | Communication card type | 0:Modbus communication card 1:Profibus-DP communication card 2:CANopen communication card 3:CANlink communication card | 0 | \$ | F01C |

Group P02: Motor 1 Parameters

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|---------------------------------------------------------------------------------------------------------------------------|--------------------|--------|---------|
| P02.00 | Motor type selection | 0:common asynchronous motor 1:variable frequency asynchronous motor 2:permanent magnetic synchronous motor | 0 | | F100 |
| P02.01 | Rated motor power | 0.1KW~1000.0KW | Model dependent | | F101 |
| P02.02 | Rated motor voltage | 1V~2000V | Model dependent | | F102 |
| P02.03 | Rated motor current | 0.01A~655.35A (inverter Power<=55KW) 0.1A~6553.5A (inverter Power>55KW) | Model dependent | | F103 |
| P02.04 | Rated motor frequency | 0.01Hz∼Maximum Frequency | Model dependent | | F104 |
| P02.05 | Rated motor rotational speed | 1rpm \sim 65535rpm | Model dependent | | F105 |
| P02.06 | stator | 0.001Ω~65.535Ω | Tune | | F106 |

Chapter 2 Function Code Table



| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|--------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|-------------------|--------|---------|
| | resistance (asynchronous motor) | (inverter Power<=55KW) $0.0001\Omega \sim 6.5535\Omega$ (inverter Power>55KW) | parameter | | |
| P02.07 | rotor resistance (asynchronous motor) | 0.001Ω~65.535Ω (inverter Power<=55KW) 0.0001Ω~6.5535Ω (inverter Power>55KW) | Tune parameter | | F107 |
| P02.08 | leakage inductive Reactance (asynchronous motor) | 0.01mH~655.35mH (inverter Power<=55KW) 0.001mH~65.535mH (inverter Power>55KW) | Tune parameter | | F108 |
| P02.09 | mutual inductive Reactance (asynchronous motor) | 0.1mH~6553.5mH (inverter Power<=55KW) 0.01mH~655.35mH (inverter Power>55KW) | Tune parameter | | F109 |
| P02.10 | No load current (asynchronous motor) | 0.01A~P02.03(inverter Power<=55KW) 0.1A~P02.03(inverter Power>55KW) | Tune parameter | | F10A |
| P02.37 | Auto-turning | 0:No auto-turning 1:Asynchronous motor static auto-turning 2:Asynchronous motor | | | |
| | Auto-turning selection | complete auto-turning 11:Synchronous motor static auto-turning 12:Synchronous motor complete auto-turning | 0 | | F125 |

Group P04: V/F Control Parameters

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Addres s |
|------------------|----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|------------|-------------|
| P04.00 | VF curve setting | 0:Linear V/F 1:Multi-point V/F 2:Square V/F 3:1.2 power V/F 4:1.4 power V/F 6:1.6 power V/F 8:1.8 power V/F 9:Reserved 10:VF complete separation 11:VF half separation | 0 | | F300 |
| P04.01 | Torque boost | 0.0%:(Automatic torque boost) 0.1%~30.0% | Model dependent | \diamond | F301 |



| | | | C | hapter 2 | Funct | ion Code Ta |
|------|-------------|-----------------------------------------|-----------------------------|--------------------|------------|-------------|
| Func | ction de | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Addres s |
| P04 | .02 | Cut-off frequency of torque boost | 0.00Hz∼maximum frequency | 15.00Hz | | F302 |
| P04 | .09 | VF slip compensation gain | 0.0%~200.0% | 0.0% | \diamond | F309 |
| P04 | .10 | VF over- excitation gain | 0~200 | 64 | \diamond | F30A |
| P04 | .11 | VF oscillation suppressing gain | 0~100 | Model dependent | \diamond | F30B |

Group P05: Input Terminals

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|--------|---------|
| P05.00 | DI1 function selection | 0:No function | 1 | | F400 |
| P05.01 | DI2 function selection | 2:Reverse run(REV) 3:Three-line control | 2 | | F401 |
| P05.02 | DI3 function selection | 4:Forward JOG(FJOG) 5:Reverse JOG(RJOG) 6:Terminal UP | 8 | | F402 |
| P05.03 | DI4 function selection | 7:Terminal DOWN 8:Coast to stop 9:Fault reset(RESET) | 9 | | F403 |
| P05.04 | DI5 function selection | 10:Run Pause 11:Normally open input of | 12 | | F404 |
| P05.05 | DI6 function selection | 12:Multi-reference terminal 1 13:Multi-reference terminal 2 | 13 | | F405 |
| P05.06 | DI7 function selection | 14:Multi-reference terminal 3 15:Multi-reference terminal 4 16:Acceleration/Deceleration | 0 | | F406 |
| P05.07 | DI8 function selection | time selection terminal 1 17:Acceleration/Deceleration time selection terminal 2 18:Frequency source switchover 19:UP/DOWN setting clear (terminal\operation panel) 20:Command source switchover terminal 21:Acceleration/Deceleration prohibited 22:PID pause 23:PLC status reset 24:Swing pause 25:Counter input | 0 | | F407 |



| Function | LED/OLED | | Factory | | |
|----------|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|------------|---------|
| Code | Operation | Setting range | settings | Modify | Address |
| 0000 | panel display | | oottingo | | |
| | | 26:Counter reset 27:Length count input 28:Length reset 29:Torque control prohibited 30:Pulse frequency input (only valid for DI5) 31:Reserved 32:Inmediate DC braking 33:Normally closed input of external fault 34:Frequency modification enable 35:Reverse PID action direction 36:External stop terminal 1 37:Command source switchover terminal 2 38:PID integral pause 39:Switchover between main frequency source X and preset frequency 40:Switchover between main frequency source Y and preset frequency 41:Motor selection terminal 1 42:Motor selection terminal 1 42:Motor selection terminal 2 43:PID parameter switchover 44:User-defined fault 1 45:User-defined fault 1 45:User-defined fault 2 46:speed control/ torque control Switchover 47:Emergency stop 48:External stop terminal 2 49:Deceleration DC braking 50:Clear the current running time 51:Forced to run the terminal when below undervoltage point 52:Deceleration stop function, but Jog effective 53: PV Enable disable 54: PV Voltage given enable 55: PV Input and working frequency power supply switching | | | |
| P05.08 | Reserved | | 0 | | F408 |
| P05.09 | Reserved | - | — | | F409 |
| P05.10 | DI filter time | 0.000s~1.000s | 0.010s | \diamond | F40A |
| P05.11 | Terminal command mode | 0:two-line mode 1 1:two-line mode 2 2:three-line mode 1 | 0 | | F40B |



Function Code Table

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------------------------------|----------------------|------------------|------------|---------|
| | | 3:three-line mode 2 | | | |
| P05.12 | Terminal UP/DOWN rate | 0.001Hz/s∼65.535Hz/s | 1.00Hz/s | \diamond | F40C |
| P05.13 | AI curve 1 minimum input | 0.00V~P05.15 | 0.00V | \diamond | F40D |
| P05.14 | Correspondi ng setting of Al curve 1 minimum input | -100.0%~+100.0% | 0.0% | \$ | F40E |
| P05.15 | AI curve 1 maximum input | P05.13~+10.00V | 10.00V | \diamond | F40F |
| P05.16 | Correspondi ng setting of Al curve 1 maximum input | -100.0%~+100.0% | 100.0% | \$ | F410 |
| P05.17 | AI1 filter time | 0.00s~10.00s | 0.10s | \diamond | F411 |
| P05.18 | AI curve 2 minimum input | 0.00V~P05.20 | 0.00V | \diamond | F412 |
| P05.19 | Correspondi ng setting of AI curve 2 minimum input | -100.0%~+100.0% | 0.0% | \$ | F413 |
| P05.20 | AI curve 2 maximum input | P05.18~+10.00V | 10.00V | \diamond | F414 |
| P05.21 | Correspondi ng setting of AI curve 2 maximum input | -100.0%~+100.0% | 100.0% | \$ | F415 |
| P05.22 | AI2 filter time | 0.00s~10.00s | 0.10s | \diamond | F416 |
| P05.23 | AI curve 3 minimum input | -10.00V~P05.25 | -10.00V | \diamond | F417 |
| P05.24 | Correspondi ng setting of | -100.0%~+100.0% | -100.0% | \diamond | F418 |



| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| | AI curve 3 minimum input | | | | |
| P05.25 | AI curve 3 maximum input | P05.23~+10.00V | 10.00V | \diamond | F419 |
| P05.26 | Correspondi ng setting of AI curve 3 maximum input | -100.0%~+100.0% | 100.0% | \$ | F41A |
| P05.27 | AI3 filter time | 0.00s~10.00s | 0.10s | \diamond | F41B |
| P05.34 | Setting for AI less than minimum input | Unit's digit:Setting for Al1 less than minimum input 0:Minimum value 1:0.0% Ten's digit:Setting for Al2 less than minimum input,the same as Al1. Hundred's digit:Setting for Al3 less than minimum input,the same as Al1. | 000 | \$ | F422 |

Group P06: Output Terminals

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| P06.00 | SP terminal output mode | 0:Pulse output(SPP) 1:Switch signal output(SPR) | 0 | \diamond | F500 |
| P06.01 | SPR function | 0:No output | 0 | \diamond | F501 |
| P06.02 | Relay function (TA1-TB1-TC1) | 2:Fault output(stop) 3:Frequency-lever detection FDT1 output 4:Frequency reached 5:Zero speed running(No output at stop) 6:Motor overload pre-warning 7:inverter overload pre- warning 8:Set count value reached 9:Designated count value reached 10:Length reached 11:PLC cycle complete 12:Accumulative running time reached 13:Frequency limited | 2 | \$ | F502 |



Function Code Table

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| | Relay function (TA1-TB1-TC1) | 14:Torque limited 15:Ready for run 16:Al1>Al2 17:Frequency upper limit reached 18:Frequency lower limit reached 19:Under-voltage state output 20:Communication setting 21:Reserved 22:Reserved 23:Zero-speed running(Having output at stop) 24:Accumulative power-on time reached 25:Frequency-lever detection FDT2 output 26:Frequency 1 reached 27:Frequency 2 reached 28:Current 1 reached 29:Current 2 reached 30:Timing reached 31:Al1 input exceeded 32:Load becoming 0 33:Reverse running | | | |
| P06.03 | Extension card relay function (TA2-TB2-TC2) | 35:Module temperature reached 36:output current exceeded | 0 | \diamond | F503 |
| P06.04 | SPA function selection | 37: Frequency lower limit reached(Having output at stop) 38: Alarm output(inverter continue to run) 39: Motor overheat pre- warning 40: Current running time reached 41: Fault output (Fault Stop) 42: PV working frequency input switching threshold reached (threshold judgment) 43: PV working frequency input switching (S input determination) 44: The light is weak | 1 | \$ | F504 |
| P06.06 | SPP function selection | 0:Running frequency 1:Set frequency | 0 | \diamond | F506 |
| P06.07 | AO1 function selection | 2:Output current 3:Output torque 4:Output power | 0 | \diamond | F507 |

Chapter 2 Function Code Table



| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| | | 5:Output voltage 6:Pulse input (100.% corresponds to 100.0KHz) 7:Al1 8:Al2 9:Al3(Extension card) 10:Length 11:Count value 12:Communication setting 13:Motor rotational speed 14:Output current(100.0% corresponds to 1000.A) 15:Output voltage (100.0% corresponds to 1000.0V) 16:Reserved | | | |
| P06.09 | Maximum SPP output frequency | 0.01KHz~100.00KHz | 50.00KHz | \diamond | F509 |
| P06.11 | AO1 gain | -10.00~+10.00 | 1.00 | \diamond | F50B |
| P06.13 | Extension card AO2 gain | -10.00~+10.00 | 1.00 | \diamond | F50D |
| P06.18 | TA1-TB1- TC1output relay time | 0.0s~3600.0s | 0.0s | \$ | F512 |
| P06.19 | TA2-TB2- TC2 output relay time | 0.0s~3600.0s | 0.0s | \$ | F513 |

Group P07: Start/Stop Control

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|-------------------------------------------|------------------|------------|---------|
| P07.03 | Start-up frequency | 0.00Hz~10.00Hz | 0.00Hz | \diamond | F603 |
| P07.10 | Stop mode | 0:Deceleration to stop 1:Coast to stop | 0 | \diamond | F60A |

Group P08: Operation panel and display

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|-------------------|------------------|--------|---------|
| P08.00 | MF key | 0:MF key disabled | 3 | | F700 |



| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| | function selection | 1:Switchover between operation panel and remote command control(terminal or communication) 2:Switchover between forward rotation and reverse rotation 3:Forward JOG 4:Reverse JOG | | | |
| P08.01 | STOP/RESE T key function | 0:STOP/RESET key enable only in operation panel control 1:STOP/RESET key enable in any operation mode | 1 | \diamond | F701 |

Group P09: Auxiliary Functions

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|------------------------------------------------------------------------------------|-----------------------------------------------------------------|------------------|------------|---------|
| P09.00 | JOG running frequency | 0.00Hz \sim Maximum frequency | 2.00Hz | \diamond | F800 |
| P09.01 | JOG acceleration time | 0.0s∼6500.0s | 20.0s | \diamond | F801 |
| P09.02 | JOG deceleration time | 0.0s∼6500.0s | 20.0s | \diamond | F802 |
| P09.14 | Running mode when set frequency lower than frequency lower limit | 0:Run at frequency lower limit 1:Stop 2:Run at zero speed | 0 | \$ | F80E |
| P09.18 | Start-up protection | 0: NO 1: YES | 0 | \diamond | F812 |

Group P10: Fault and Protection

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|---------------|------------------|------------|---------|
| P10.09 | Fault auto reset times | 0~20 | 0 | \diamond | F909 |
| P10.45 | Forced to run low voltage enable | 0~1 | 1 | \diamond | F92D |



| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|--------------------------------------------------------------------|-------------------------------------------------------|------------------|------------|---------|
| P10.46 | Vector Zero- speed running output enable | 0~1 | 0 | \diamond | F92E |
| P10.59 | Action selection at instantaneous power failure | 0:Invalid 1:Deceleration 2:Deceleration to stop | 0 | \$ | F93B |
| P10.60 | Instantaneous stop non-stop frequency switching point | 80.0%~100.0% | 100.0% | \$ | F93C |
| P10.61 | Voltage rally judging time at instantaneous power failure | 0.00s~100.00s | 0.50s | \diamond | F93D |
| P10.62 | Action judging voltage at instantaneous power failure | 60.0%∼100.0%(Standard bus voltage) | 80.0% | \diamond | F93E |
| P10.63 | protection of load lost | 0: Invalid 1: Valid | 1 | \diamond | F93F |

Group P15: Special functions for PV inverters

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| P15.00 | PV inverter selection | 0:Invalid 1:Enable 0 means the function is invalid and the group of parameters can not be used 1 means the function enabled and P15 group parameters can be adjusted | 1 | \diamond | FE00 |



Function Code Table

| Function | LED/OLED | | Factory | | |
|----------|---------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|--------|---------|
| Code | Operation panel display | Setting range | settings | Modify | Address |
| P15.01 | Vmpp voltage reference | 0:Voltage reference 1:Max.power tracking 0 means to apply voltage reference mode. The reference is a fixed value and given by P15.02. 1 means to apply the reference voltage of Max.power tracking.The voltage is changing until the system is stable. No matter what kind of reference voltage is applied, if the bus voltage is higher than reference voltage, the target frequency will change to the upper limit of PI output frequency and if the bus voltage, the target frequency will change to the lower limit of PI output get frequency will change to the lower limit of PI output frequency. Note:If terminal 54 is valid, the function is invalid. | 1 | \$ | FE01 |
| P15.02 | Vmpp voltage keyboard reference | 0.0~1000.0Vdc If P15.01 is 0, the reference voltage is given by P15.02 For 380v motor as 530VDC(default) For 220v motor as 260VDC(default) | 530.0V | \$ | FE02 |
| P15.03 | PI control deviation | 0.0~100.0%(100.0% corresponds to P15.02) If the ratio percentage of bus voltage to reference voltage, which is abs(bus voltage-reference voltage)*100.0% / reference voltage, if the value exceeds the deviation limit of P15.03, PI adjustment is available, otherwise, there is no PI adjustment and the value is defaulted to be 0.0% Abs: the absolute value | 0.0% | \$ | FE03 |
| P15.04 | Upper frequency of PI output | P15.05~100.0%(100.0% corresponds to P01.10) P15.04 is used to limit the Max.value of target frequency, 100% corresponds to P01.10. After PI adjustment, the target frequency can not exceed the upper limit. | 100.0% | \$ | FE04 |
| P15.05 | Lower frequency of PI output | 0.0% ~P15.04(100.0% corresponds to P01.10) P15.05 is used to limit the Min.value of target frequency,100% corresponds to P01.10. After PI adjustment, the target frequency can not exceed the lower limit. | 20.0% | \$ | FE05 |



| Function | LED/OLED | | Factory | | |
|----------|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|------------|---------|
| Code | Operation | Setting range | settings | Modify | Address |
| 0000 | panel display | | oottingo | | |
| P15.06 | KP1 | $0.00 \sim 100.00$ The proportion coefficient 1 of the target frequency. The bigger the value is the stronger the effect and faster the adjust is. | 20.00 | \diamond | FE06 |
| P15.07 | KI1 | $0.00 \sim 100.00$ The integral coefficient 1 of the target frequency. The bigger the value is, the stronger the effect and faster the adjustment is. | 1.00 | \diamond | FE07 |
| P15.08 | KP2 | $0.00 \sim 100.00$ The proportion coefficient 2 of the target frequency. The bigger the value is, the stronger the effect and the faster the adjustment is. | 40.00 | \diamond | FE08 |
| P15.09 | KI2 | $0.00 \sim 100.00$ The integral coefficient 2 of the target frequency. The bigger the value is, the stronger the effect and faster the adjustment is. | 4.00 | \diamond | FE09 |
| P15.10 | PI switching point | 0.0~6553.5Vdc If the absolute value of bus voltage minus the reference value is bigger than P15.10,it will switch to P15.08 and P15.09: otherwise it is P15.06 and P15.07. | 50.0V | \diamond | FE0A |
| P15.11 | Water level control | 0:Invalid 1:Al1 2:Al2 3:Al3 The function is invalid if select 0. 1-3 is the reference from the simulating signal source of water level control. After selecting the simulating signal source,P15.12,P15.13,P15.14 and P15.15 are valid. | 0 | \$ | FE0B |
| P15.12 | Water level threshold | 0.0~100.0% If the simulating signal is less than the water level threshold and keep in the state after the delay time set by P15.13, report A-tF and dormant. If the time is not reached, the signal is bigger than the water level threshold, the time will be cleared automatically. When the signal time is shorter than the water level threshold time, the time will be counted again. | 25.0% | \$ | FE0C |
| P15.13 | Full water | 0∼1000.0s | 6.0s | \diamond | FE0D |



Function Code Table

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|---------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| P15.14 | Non-water delay | 0~1000.0s Time setting of non-water delay. In the full water pre-warning,if the detected simulating signal is bigger than the value set by P15.12, it begins to count the delay time. After lasting for the time set by P15.14, the pre-warning will be cleared. Under the condition of non continuous, delay time will be reset automatically. | 60.0s | \$ | FEOE |
| P15.15 | Hydraulic probe damage | 0.0~100.0% 0.0%:Invalid. If it is not 0.0%, when the signal is longer than P15.15, it will report "E.tSF"fault directly and stop. | 0.0% | \diamond | FE0F |
| P15.16 | Operation time of water pump underload | 0.0~1000.0s Set the operation time of underload operation. Under the continuous underload operation,it will report A-LL if the operation time is reached. | 60.0s | \diamond | FE10 |
| P15.17 | Current detection of underload operation | 0.0%:Automatic detection 0.1 \sim 100% If it's 0.0%, it is determined by the inverter. If it's NOT 0.0%, it's determined by P15.17. 100.0% corresponds to the rated motor current. If the target frequency and the absolute value of the ramp frequency is less than or equal to P15.19, and the current is less than P15.17, after the time set by P15.16, it will report underload fault. Otherwise, it will operate normally. If the state is not continuous, the delay counting will be cleared automatically. | 0.0% | \$ | FE11 |
| P15.18 | Underload reset delay | 0.0~1000.0s Underload reset delay The operation time and reset time are counted at the same time during underload, and it's bigger than P15.16 generally to ensure underload pre-warning will be reported. After the time set by P15.18-P15.16, it will reset. If the value is the same as P15.16, it will reset when report underload pre-warning. | 120.0s | \$ | FE12 |



| Function Code | LED/OLED Operation | Setting range | Factory settings | Modify | Address |
|------------------|-------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| P15.19 | Lag frequency | 0.00~200.00Hz P15.19 is the lag frequency for the analysis of underload operation. If the target frequency and the absolute value of the ramp frequency is less than or equal to P15.19, the current will be compared. | 0.30Hz | \$ | FE13 |
| P15.20 | Delay time of weak light | 0.0s~3600.0s Delay time of weak light If the output frequency is less than or equal to the lower limit of PI output frequency and the state lasts for the set value, it will report A-LS and dormant. If the state is not continuous, the delay counting will be cleared automatically. Note: If the bus voltage is lower than +50.0V, it will report directly and no need to wait for the set time | 100.0s | \$ | FE14 |
| P15.21 | Delay time of wake-up at weak light | 0.0s~3600.0s Delay time of wake-up at weak light. After the delay time, the pre- warning time of weak light will be cleared and operate again. | 300.0s | \diamond | FE15 |
| P15.22 | Initial reference voltage display | 0∼2000.0V | 0 | \diamond | FE16 |
| P15.23 | Mini voltage reference of Max.power tracking | 0.0~P15.24 Valid in MPPT Ma.tracking voltage, the Mini.tracked voltage. Track in the range of P15.23- P15.24. P15.24 needs to be bigger than P15.23.the less the difference the faster the tracking is. But the Max.voltage needs to be in the range. P15.23 and P15.24 can be adjusted according to site operation. For 380v motor as 450VDC(default) For 220v motor as 260VDC(default) | 450.0V | \$ | FE17 |
| P15.24 | Max.voltage reference of Max.power tracking | P15.23~P15.28 Valid in MPPT Max.tracking voltage, the Max.tracked voltage. For 380v motor as 550VDC(default) For 220v motor as 310VDC(default) | 550.0V | \diamond | FE18 |
| P15.25 | Adjustment of initial reference voltage | 0.0~200.0V MPPT begins to change from the reference voltage. Initial reference voltage=Bus voltage-P15.25. | 2.0V | \diamond | FE19 |



Function Code Table

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| P15.26 | Upper and lower limit time of Vmppt | 0.0~10.0s When P15.26 is set to 0.0, the automatic adjustment is invalid. If it's NOT 0.0, the upper and lower limit of Vmppt will be adjusted automatically after the time set by P15.26. The medium value is the current bus voltage and the limit is P15.27. Means:Maximum/minimum reference voltage=current bus voltage±P15.27 and it will update to P15.23 and P15.24 at the same time. | 0.0s | \$ | FE1A |
| P15.27 | Upper and lower limit of Vmppt | 20.0 \sim 100.0V The adjustment of the upper and lower limit. | 30.0V | \diamond | FE1B |
| P15.28 | Maximum value of Vmppt | P15.24~6553.5V The upper limit can not exceed the P15.28 when Vmppt is maximum value. For 380v motor as 570VDC(default) For 220v motor as 330VDC(default) | 570.0V | \$ | FE1C |
| P15.29 | Voltage sample of the solar output | 0:Invalid 1:AI1 2:AI2 2:AI3 No sample input when the selection is 0. | 0 | • | FE1D |
| P15.30 | Switch to the threshold of power frequency input | 0.0%~P15.31 If the value is lower than the threshold,it can switch to power frequency input through the relay output. If the value is 0.0%,it's invalid. 100.0% corresponds to 10V or 20mA. | 5.0% | \$ | FE1E |
| P15.31 | Switch to the threshold of solar input | P15.30 \sim 100% If the value is higher than the threshold, it can switch to solar input through switching, the threshold needs to be higher than the threshold of P15.30. If the value is 0.0%, it's invalid. 100% corresponds to 10V or 20mA. | 10.0% | \$ | FE1F |

Group P17: Function code management

| Function | LED/OLED | | Factory | | |
|----------------|---------------|---------------|----------|------------|------|
| Code | Operation | Setting range | settings | Address | |
| Code | panel display | | | | |
| D 47.00 | User | 0.05505 | 0 | ~ | 4500 |
| P17.00 | password | 0~65535 | 0 | \diamond | 1F00 |



| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|-------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|------------|---------|
| | Barameter | 0:No operation 01:Recovery to factory settings, not including the motor parameters 02:Recovery to factory settings, | | | |
| P17.01 | initialization | including the motor parameters 03:Clear history informations 04:Recovery user backup parameters 501:Backup user's current parameters | 0 | \diamond | 1F01 |
| P17.02 | Function parameter display selection | Unit's digit:P00 group display selection 0:No display 1:Display Ten's digit:P18-P30 group display selection 0:No display 1:Display | 11 | \diamond | 1F02 |
| P17.03 | Personalize d parameter group display selection | Unit's digit:User-customized parameter group display selection 0:No display 1:Display Ten's digit:User changes the parameter group display | 00 | \diamond | 1F03 |
| | | o:No display 1:Display | | | |
| P17.04 | Modify properties of the function code | 0:Can be modified 1:Can not be modified | 0 | \diamond | 1F04 |

Group P23: Control Optimization Parameters

| Function Code | LED/OLED Operation panel display | Setting range | Factory settings | Modify | Address |
|------------------|-----------------------------------------------|-----------------------------------------------------------------------------------------|------------------|------------|---------|
| P23.06 | Under- voltage point setting | 100.0~2500.0V For 380v motor as 350VDC(default) For 220v motor as 180VDC(default) | 350.0V | \diamond | A506 |
| P23.09 | Over-volatge point setting | 200.0~2500.0V For 380v motor as 800VDC(default) For 220v motor as 400VDC(default) | 800.0V | \diamond | A509 |
| P23.10 | Low- frequency carrier on/off enable | 0: Low-frequency carrier on/off close 1: Low frequency carrier on/off open | 1 | \diamond | A50A |

Chapter 3 Commissioning guide INDICATE:

The time when the inverters operated to the lower limit of PI output frequency after starting is determined by the ACC time.

The instruction of delay time. If various delay conditions such as weak light, full water, and underload are met, the inverter will count the delay time respectively. After the separated delay time is arrived, it will report pre-warning and others are still kept. If the pre-warning is restored, but other conditions for delay are still existent, it will count after the precious time. So if the some pre-warning condition is not met, the pre-warning time will be cleared.

3-1.Wiring and commissioning steps

3-1-1.Commissioning steps during power supply

1. Wire according to the diagram and check the wiring is correct or not and then switch on Q2.



inverter....

2. Set the motor parameters

(a) Set P17.01=1, and restore to the factory settings. Set
P17.01=2,restore to the factory settings(Include motor). (b)Set
P01.02=0, and change the command to keyboard control. (c)Set
the name plate of the motor,including:
P02.01(Motor's rated power)
P02.04(Motor's rated frequency)
P02.05(Motor's rated speed(RPM))
P02.02(Motor's rated voltage)
P02.03(Motor's rated current)
<Remember to press"ENT"after setting>.

3. Detection of water yield for water pumps

Set the lower limit of output frequency P01.14=6.00Hz,stop mode P07.10=1,and coast to stop. And then,set P15.00=1 to enable the special function for water pumps,click "Run" and the default mode is MPPT,observe the running frequency and water yield. If the operation frequency or water yield is low at normal light, the motor wires may be reserved, so it is necessary to exchange the wiring.

4. PI adjustment to the water yield

If the user requires large or low water yield, it is necessary to adjust PI(P15.06 \sim P15.10) properly. The bigger PI parameters, the stronger the effect is, but the frequency fluctuation of the motor is bigger, in reserve, the lower the water yield is, the more stable the motor frequency is.

5. Commissioning of MPPT speed tracking

P15.23 and P15.24 is the minimum and maximum voltage of the power tracking in MPPT mode. If the voltage range is smaller, the faster the tracking is. But the bus voltage in normal operation needs to be in the range, otherwise, the maximum power can NOT be tracked.

Generally:

- (a) If the rated motor voltage is 415V,
- P15.23=520(Minimum reference voltage),
- P15.24=600(Maximum reference voltage).
- (b) If the rated motor voltage is 380V,
- P15.23=450(Minimum reference voltage),
- P15.24=550(Maximum reference voltage).

(c) If the rated motor voltage is 220V,

P15.23=260(Minimum reference voltage),

P15.24=310(Maximum reference voltage).

Above settings are only for reference and can be adjust according to the actual applications or by automatic adjustment.

P15.26 is used to adjust the time between the maximum and minimum voltage of MPPT and can be used with P15.27 to adjust the maximum and minimum reference voltage. The upper limit of maximum reference voltage can NOT exceed the maximum setting value of P15.28.

6.Fault setting and reset time setting of fault delay

If the pre-warning of weak light, full water and underload are needed, it's necessary to set the detection point, delay time and reset time according to the actual working. Full water/non water setting are P15.11~P15.14;

The function settings of underload are P15.16 \sim P15.19; The function setting of weak light are P15.20 \sim P15.21. Default settings can be used,too.

7.Parameters setting after normal operation

When the normal amount of water, the system is stable after commissioning.

Then set P01.02 = 3, auto operation mode when power-on, and then set the ato operation delay time as P01.20 = 5, set the auto reset times P10.09 = 5, this mode as when power-on, after the delay time will run automatically, STOP key to stop, press the RUN key to continue.

Note: 85% of P10.62 corresponds to 460V. The coefficient can be modified, but can NOT be modified to below 65% (65% corresponds to undervoltage point 350v, so it may report undervoltage fault if the actual bus voltage is less than the value).



3-1-2. Commissioning steps during grid power supply

1. Wire according to the diagram and check the wiring is correct or not.



Now switch off Q2 and then switch on Q1 .

2. After the power frequency, commission the system according to steps 2 \times 3 \times 4 \times 6 and 7 mentioned in 3-1-1.

3. Set P05.00=53, and then switch on S2(or set P15.01=0)to enable the PV voltage reference. Note: when use the back up supply, AC380V input connect with R/S/T, AC220V single phase input connect with R/T, AC220V 3-Phase input connect with R/S/T.

4. When switch to PV power supply, Just need to switch off Q1 and S2, switch on Q2.

Note: If there is no diode protection at the bus input, Q2 and Q1 can NOT be switched on at the same time, otherwise, damage may occur to the buttery board.

Chapter 4 Faults and Solutions

4-1. Fault Information and Troubleshooting

GK330 provides a total of 50 items of fault information and protective functions. Once fault occurs , the inverter implements protective functions, and stops the output, the inverter's fault relay actions, and display the fault code on operation panel.

Before contacting manufacturer for technical support, you can first determind the fault type, analyze the causes and find the solutions.

If the troubleshootings belong to the types of the following diagram ,contact the agent or manufacturer for help.

E.Inv is the overvoltage or overcurrent signal of these 21 warning information items.In most situations, E.Inv is caused by hardware overvoltage.

| Sequ ence | Fault code | Fault type | Possible causes | Solutions |
|--------------|------------|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | | Inverter unit U protection | 1、The output circuit short-circuited | Eliminate external faults Install a reactor or an |
| | | Inverter unit V protection | 2. The connecting cable of the motor is too long. 3. The module overheats 4. The internal | output filter 3、Check the air filter and cooling fan 4、Connect all cables |
| 1 E. | E.oUP | Inverter unit W protection | 4、 The internal connections Becoming loose. 5、 The main control board abnormal 6. Drive borad abnormal 7、 The inveter module abnormal | properly 5、Contact manufacturer for technical support 6、Contact manufacturer for technical support 7、Contact manufacturer for technical support |
| 2 E.oC1 | | Overcurrent E.oC1 during acceleration | The output circuit grouded or short-circuited Control mode is VC, and the motor auto-turning is not performed The acceleration time is too short Manual torque boost | Eliminate external faults Perform the motor auto-turning Increase the acceleration time Adjust the manul torque boost or V/F curve |
| | E.oC1 | | and V/F curve is not appropriate 5. The voltage is too low 6. The startup operation is performed on the rotating motor 7. A sudden load is added during acceleration 8. The inverter model is of too small power class | Adjust the voltage to normal range Select rotational speed tracking restart or start the motor after it stops Remove the added load Select an inverter of higher power class |
| 3 | E.oC2 | Overcurrent during deceleration | The output circuit grouded or short-circuited Control mode is VC,and the motor auto-turning is | Eliminate external faults Perform the motor auto-turning |

inverter....

| Sequ ence | Fault code | Fault type | Possible causes | Solutions |
|--------------|------------|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | | | not performed 3、The deceleration time is too short 4、The voltage is too low 5、A sudden load is added during deceleration 6、The braking unit and braking resistor are not installed | Increase the deceleration time Adjust the voltage to normal range Remove the added load Install the braking unit and braking resistor |
| 4 | E.oC3 | Overcurrent at constant speed | The output circuit grouded or short-circuited Control mode is SVC, and the motor auto- turning is not performed The voltage is too low A sudden load is added during deceleration The inverter model is of too small power class | Eliminate external faults Perform the motor auto-turning Adjust the voltage to normal range Remove the added load Select an inverter of higher power class |
| 5 | E.oU1 | Overvoltage during acceleration | The input voltage is too high An external force drives the motor during acceleration The acceleration time is too short The braking unit and braking resistor are not installed | Adjust the voltage to normal range Cancel the external force or install a braking resistor Increase the acceleration time Install the braking unit and braking resistor |
| 6 | E.oU2 | Overvoltage during deceleration | The input voltage is too high An external force drives the motor during deceleration The deceleration time is too short The braking unit and braking resistor are not installed | Adjust the voltage to normal range Cancel the external force or install a braking resistor Increase the deceleration time Install the braking unit and braking resistor |
| 7 | E.oU3 | Overvoltage at constant speed | The input voltage is too high An external force drives the motor during deceleration | Adjust the voltage to normal range Cancel the external force or install a braking resistor |
| 8 | E.Br | Buffer resistor overload fault | 1、The input voltage is not within the allowable range | 1、The input voltage is not within the allowable range |
| 9 | E.LU | Undervoltage | Instaneous power failure The input voltage is not within the allowable range The DC bus voltage is abnormal The rectifier bridge and | Reset the fault Adjust the voltage to normal range Contact manufacturer for technical support Contact manufacturer for technical support |



Faults and Solutions

| Sequ ence | Fault code | Fault type | Possible causes | Solutions |
|--------------|------------|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | | | buffer resistor are abnormal 5、The drive board is abnormal 6、The control board is abnormal | 5、Contact manufacturer for technical support 6、Contact manufacturer for technical support |
| 10 | E.oL1 | inverter overload | The load is too heavy or locked-rotor occurs on the motor The inverter model is of too small power class | Reduce the load and check the motor and mechanical condition Select an inverter of higher power class |
| 11 | E.oL2 | Motor overload | 1, the motor protection parameters P10.01 setting is appropriate 2, the load is too large or the occurrence of motor stall 3, the inverter model is too small power class | 1, Setting correct parameters 2, Reduce the load and check the loading conditions 3, Select an inverter of higher power class. |
| 12 | E.PHI | Input phase loss | The 3-phase power input is abnormal The drive board is abnormal The lightening board is abnormal The control board is abnormal | Eliminate external faults Contact manufacturer for technical support Contact manufacturer for technical support Contact manufacturer for technical support |
| 13 | E.PHo | Output phase loss | The cable connecting the inverter and motor is faulty The inverter's 3-phase outputs are unbalanced during the motor is running The drive board is abnormal The module is abnormal | Eliminate external faults Check whether the motor three-phase winding is normal Contact manufacturer for technical support Contact manufacturer for technical support |
| 14 | E.oH1 | Module overheat | The ambient temperature is too high The air filter is blocked The fan is damaged The thermally sensitive resistor of the module is damaged The inverter module is damaged | Lower the ambient temperature Clean the air filter Replace the damaged fan Replace the damaged thermally sensitive resistor Replace the inverter module |
| 15 | E.SET | External equipment fault | External fault signal is input via DI External fault signal is input via virtual I/0 | Reset the operation Reset the operation |
| 16 | E.CE | Communication fault | The host computer is in abnormal state The communication cable is abnormal | Check the cabling of the host computer Check the communication cabling |

Chapter 4 Faults and Solutions

inverter....

| Sequ ence | Fault code | Fault type | Possible causes | Solutions |
|--------------|------------|-----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | | | P00.28 set is improperly The communication parameters in P14 are set improperly | 3. Set the extension card parameters correctly 4. Set the communication parameters properly |
| 17 | E.CoN | Contactor fault | The drive board and power supply are abnormal The contactor is abnormal | The drive board and power supply are abnormal The contactor is abnormal |
| 18 | E.oCC | Current detection fault | 1.The connector of the control borad is not connect well 2.Auxiliary power fault 3.The HALL device fault 4.The amplify circuit is abnormal | Check the connector Contact manufacturer for technical support Contact manufacturer for technical support Contact manufacturer for technical support |
| 19 | E.TE | Motor auto- turning fault | The capacity of motor and inverter are not match The motor's parametes are not set properly The parameters between auto-turning and standard are of big deviation Auto-turning time out | Replace the inverter model Set the parameters according to the motor nameplate Auto-turning with the motor no-load Check the motor cabling and parameter setting |
| 20 | E.Enco | Encoder fault | The encoder type is incorrect The cable connection of encoder is incorrect The encoder is damaged PG card abnormal | Set the encoder type correctly based on actual situation Eliminate external fault Replace the damaged encoder Replace the PG card |
| 21 | E.EEP | EEPROM R/W fault | 1.EEPROM chip is damaged | 1、Replace the control board |
| 22 | E.INv | inverter hardware fault | 1、Overvoltage exsists 2、Overcurrent exsists | Handle based on overvoltage Handle based on Overcurrent |
| 23 | E.STG | Short circuit to ground | 1、The motor is short circuited to the ground | 1、Replace the cable or motor |
| 26 | E.Tlo | Accumulative running time reached fault | 1. Accumulative running time reaches the setting value | 1 Clear the record through parameter initialization function |
| 27 | E.USE1 | User-defined fault 1 | The user-defined fault signal is input via DI The user-defined fault signal is input via virtual IO | Reset operation Reset operation |

inverter....

Chapter 4 Faults and Solutions

| Sequ ence | Fault code | Fault type | Possible causes | Solutions |
|--------------|------------|------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 28 | E.USE2 | User-defined fault 2 | 1 The user-defined fault 2 signal is input via DI 2、The user-defined fault 1 signal is input via virtual IO | 1、Reset operation 2、Reset operation |
| 29 | E.PUTO | Accumulative power-on time reached fault | Accumulative power- on time reaches the setting value | 1、Clear the record through parameter initialization function |
| 30 | E.LOAD | Load lost fault | 1、The inverter's running current is lower than P10.64 | 1、Make sure whether the load is connected or parameters of P10.64、 P10.65 are correct |
| 31 | E.Pld | PID feedback lost during running | 1、PID is lower than the P11.26 setting value | 1、Check PID feedback signal or set P11.26 to a proper value |
| 40 | E.CBC | Pulse by pulse current limit fault | The load is too heavy or locked-rotor occurs on the motor The inverter is of too small power class | Reduce the load and check the motor and mechanical condition Select an inverter of higher power class |
| 41 | E.SrUN | Motor switchover fault during running | 1. Change the selection of the motor via terminal during running of the inverter | 1、Perform motor switchover after inverter stops. |
| 42 | E.SSD | Too large speed deviation fault | 1. The encoder parameters are set improperly 2. The motor auto-turning is not performed 3. P10.69 and P10.60 are set incorrectly | Set the encoder parameters properly Perform the motor auto-turning Set P10.69 and P10.60 correctly based on actual situation |
| 43 | E.oS | Motor over- speed fault | The encoder parameters are set incorrectly The motor auto-turning is not performed P10.69 and P10.60 are set incorrectly | Set the encoder parameters properly Perform the motor auto-turning. Set P10.69 and P10.60 correctly based on actual situation |
| 44 | E.oH2 | Motor overheat fault | The cabling of temperature sensor becomes loose The temperature of motor is too high | Check the temperature sensor cabling and eliminate the cabling fault Lower the carrier frequency or adopt other heat radiation measures. |
| 45 | E.INIT | Initial position fault | 1、The motor parameters are of large deviation of the actual. | 1、Check that the motor parameters are set correctly and whether the setting of rated motor current is too small |
| 46 | E.Load | Electronic underload fault | The inverter will report the underload pre-alarm according to the set value | Check the load and the underload pre-alarm |

| Sequ ence | Fault code | Fault type | Possible causes | Solutions |
|--------------|------------|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| 47 | E.tSF | Hydraulic probe damage | Hydraulic probe damage and the feedback signal wire are not connected well. | Check the wiring and change the probe. |
| 48 | A-LS | Weak light Pre-warning | The output frequency is lower than or equal to the lower limit of PI output frequency and keep to reach to the weak light delay time. | Check the lower limit of PI output and the setting value of delay time. |
| 49 | A-LL | Underload pre-warning | The water pump runs at a small load and the operation time reaches the set time. | Check the water level of the resource and the pre- warning point of underload. |
| 50 | A-tF | Full-water pre-warning | The feedbacked water leve is lower than the threshold and keep it for a certain time. | Check the pre-warning point of the water level. |

4-2. Common Faults and Solutions

You may come across the following faults during the use of the inverter, refer to the following table for simple fault analysis:

| 1 | There is no display at power-on | There is no power supply to inverter or the power input to inverter is too low; The power supply of the drive board of AC dirve is faulty; The rectifier bridge is damaged; The buffer-resistor of the inverter is damaged; The control board and the operation panel are faulty ; The cabling between control board and drive board and operation panel breaks ; | Check the input power supply; Check the DC bus voltage; Re-connect the 8-core or 28-core cables. Contact manufacturer for technical support; |
|---|------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2 | GK330 is displayed at power-on | The cable between control board and drive board is in poor contact; Related components of the control board are damaged; Re-connect the 8-core or 28- core cable ; The motor or the motor cable is short-circuited to ground; Contact manufacturer for technical support; The HALL device is faulty ; The power input to the inverter is too low; | |

inverter.....

Chapter 4 Faults and Solutions

| 3 | "E.STG"is displayed at power-on | The motor or the motor cable is short-circuited to ground: The inverter is damaged; | Measure the insulation of the motor and the motor output cable with a Megger; Contact manufacturer for technical support; |
|---|--------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4 | The inverter display is normal .But GK330 is displayed after running and stops immediately | The cooling fan is damaged or locked-rotor occurs; The external control terminal cable is short circuited; | Replace the cooling fan ; Eliminate the external short circuited fault ; |
| 5 | E.oH1(module overheat) fault is reported frequency | The setting of carrier frequency is too high. Lower the setting of the carrier frequency(P01.15). The cooling fan is damaged or locked-rotor occurs. Replace the cooling fan and clean the air filter . Components inside inverter are damaged(Thermal coupler or others) The motor and the motor cabling: The setting parameters of the inverter is faulty(The motor parameters); | |
| 6 | The motor does not rotate after the inverter runs | The motor and the motor cabling: The setting parameters of the inverter is faulty(The motor parameters); The cable between control board and drive board is in poor contact; The control board is faulty; | Ensure the cable between the inverter and motor is normal; Replace the motor and clear the mechanical faults ; Check the reset motor parameters ; |
| 7 | DI terminals are invalid | The parameters are set incorrectly: External signals is incorrect; The jump bar between OP and +24V becomes loose; The control board is faulty; | Check and reset the corresponding parameters of P05 group; Re-connect the external signal cable; Ensure the jump bar between OP and +24V; Contact manufacturer for technical support; |

| 8 | The motor speed is always low in CLVC control mode | The encoder is faulty; The encoder cable is connected incorrectly or in poor contact; The PG card is faulty; The control board is faulty; | Replace the encoder and ensure the cable connect properly; Replace the PG card; Contact manufacturer for technical support; | | |
|----|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|
| 9 | Replace the encoder and reconfirm the wiring; Replace PG card; Seeking services; | The motor parameters are set improperly; The acceleration /deceleration time is improper; The load fluctuates; | Reset the motor parameters or perform the motor auto-turning; Set the proper acceleration /deceleration time; Contact manufacturer for technical support; | | |
| 10 | E.CoN is reported upon power-on or running | The soft startup contactor is not picked up | Check whether the contactor cable is loose; Check whether the contactor is faulty; Check whether 24V power supply of the contactor is faulty; Contact manufacturer for technical support; | | |
| 11 | "88888" is displayed upon power-on | Related components of control board are damaged; | Replace the control board | | |

inverter....

Chapter 5 Recomended solar panels

Chapter 5 Recommended solar panels

| Inverter Model | Max.DC input current (A) | Open-circuit voltage degree of solar panels | | | | | | | | | |
|----------------|--------------------------------|---------------------------------------------|-------------------------------|----------------------|-------------------------------|----------------------|-------------------------------|----------------------|-------------------------------|----------------------|-------------------------------|
| | | 20±3V | | 30±3V | | 36±3V | | 42±3V | | | |
| | (A) | Panels power ±5Wp | Panels per string* strings | Panels power ±5Wp | Panels per string* strings | Panels power ±5Wp | Panels per string* strings | Panels power ±5Wp | Panels per string* strings | Panels power ±5Wp | Panels per string* strings |
| GK330-0R7D-3B | 4.2 | 30 | 29*1 | | | | | | | | |
| GK330-1R5D-3B | 6.1 | 60 | 30*1 | | | | | | | | |
| GK330-2R2D-3B | 7.1 | 90 | 30*1 | | | 145 | 18*1 | 175 | 15*1 | | |
| GK330-003D-3B | 9.6 | 60 | 30*2 | | | 195 | 17*1 | 220 | 15*1 | | |
| GK330-004D-3B | 16.5 | 85 | 28*2 | 220 | 22*1 | 140 | 17*2 | 160 | 15*2 | | |
| GK330-5R5D-3B | 23.9 | | | | | 195 | 17*2 | 220 | 15*2 | | |
| GK330-7R5D-3B | 30.6 | | | 215 | 21*2 | 175 | 17*3 | 200 | 15*3 | 300 | 15*2 |
| GK330-011D-3B | 39.2 | | | 200 | 22*3 | 195 | 17*4 | 220 | 15*4 | | |
| GK330-015D-3B | 49.0 | | | 205 | 22*4 | 200 | 18*5 | 240 | 15*5 | 300 | 15*4 |
| GK330-018D-3B | 58.6 | | | 200 | 27*4 | 200 | 18*6 | 240 | 15*6 | 300 | 12*6 |
| GK330-022D-3B | 71.5 | | | | | 200 | 18*8 | 220 | 15*8 | 300 | 15*6 |
| GK330-030D-3B | 97.6 | | | | | 200 | 18*10 | 240 | 15*10 | 300 | 15*8 |
| GK330-037D-3B | 120.3 | | | | | | | 240 | 15*12 | 300 | 15*8 |